

// USER GUIDE · LED POSTERS · ALL-IN-ONE



SP SERIES OWNER'S GUIDE

ALL-IN-ONE P2.5 LED POSTER · GETTING STARTED & EVERYDAY CONTROL

ROLL IT IN · PLUG IT IN · ON THE AIR

01 // MEET YOUR POSTER

Everything is already inside.

Every SP poster has a NovaStar T40 media player and speakers built in. There is no external processor, rack, or PC: the poster stores your content and plays it on its own, and you control it from a free phone app or from the cloud.

P2.5

PIXEL PITCH

256 × 768

PIXELS / UNIT

NovaStar T40

BUILT-IN PLAYER

Built-In

SPEAKERS

Wall Outlet

STANDARD POWER

In the case: poster with wheeled base and acrylic-protected face, power cable, and link cables. Depending on your order you may also have flight cases and a spare-parts kit.

02 // ON THE AIR IN THREE STEPS

1

ROLL IT INTO PLACE AND PLUG IT IN

Unlock the casters, roll the poster where you want it, lock the casters, and plug into any standard wall outlet (about 160 W per unit). The poster powers up and starts playing whatever is stored on it.

2

GET THE FREE APP

Install ViPlex Handy from the App Store or Google Play. In the app, connect to the poster's own Wi-Fi network. The network name and password are printed on the sticker on the back of the unit.

3

SEND YOUR CONTENT

In ViPlex Handy, pick your poster, add photos or videos from your phone into a playlist, and press publish. The content copies to the poster and starts playing. That is the whole workflow.

03 // THREE WAYS TO CONTROL IT

TOOL	WHERE IT RUNS	BEST FOR
ViPlex Handy	iPhone / Android app, free	Everyday use. Connect over Wi-Fi, publish photos and video, adjust brightness and volume, restart the poster, run one unit or a synced group.
ViPlex Express	Windows PC, free download from NovaStar	Bigger content pushes from a laptop on the same network, playlist building with precise layouts, and screen configuration.
VNNOX Cloud	Web browser, free account	Fleet control. Once posters are on venue Wi-Fi, schedule and update every unit in every location remotely, from anywhere, per poster or as a group.

Fleet tip: the poster's own Wi-Fi hotspot is for direct control standing near the unit. To unlock remote and multi-location control, join each poster to the venue's Wi-Fi in the app, then manage everything from VNNOX in a browser.

04 // BUILDING CONTENT THAT FITS

CANVAS SIZES

1 POSTER	256 × 768 px
2 POSTERS	512 × 768 px
3 POSTERS	768 × 768 px
4 POSTERS	1024 × 768 px

Build content at the size of your full wall. Posters can stand side by side as-is, with a slim border where the cabinets meet. For a true seamless wall, remove the edge frames on the sides where units join (5 screws on each side, 3 across the top); the acrylic face comes off with the frames. Fast-lock the cabinets together, then in the app open **Screen Management** and switch on **Multi-Screen Mosaic**: set the orientation and the number of screens, and the group plays as one seamless canvas. Frames and acrylic go back on in minutes when you return a unit to standalone duty.

FILE FORMATS

- ▶ Images: JPG, PNG, GIF, BMP
- ▶ Video: MP4 is the safe bet; common formats like MOV and AVI also play
- ▶ Audio plays through the built-in speakers, so a video with sound needs no outboard audio
- ▶ Text and simple layouts can be built right in the app

SCHEDULE IT

Set playlists to run by time of day or day of week: menus at lunch, promos at night, dark after close. Set it once and the poster runs itself.

BRIGHTNESS & VOLUME

Adjust brightness and speaker volume from the app. Turn brightness down for dim rooms and evening events; the panel is rated 600+ nits for bright retail floors.

GROUPS & WALLS

Run each poster independently with its own content, or group them so one publish hits every unit in perfect sync, whether they are locked into one wall or spread around the room.

REMOTE FLEET CONTROL

With posters on Wi-Fi, VNNOX gives you one dashboard for every unit you own, across every location: publish, schedule, monitor, and restart remotely.

06 // CARE & HANDLING

- ▶ The acrylic face protects the LEDs in day-to-day use; clean it with a soft dry cloth, never solvents or spray directly on the face
- ▶ Lock the casters whenever the poster is standing; use two people on ramps and thresholds
- ▶ Indoor use only; keep the poster out of rain and away from standing water
- ▶ Transport in the flight case when possible, face protected, unit upright
- ▶ Running a seamless wall? Keep each unit's frames, acrylic face, and screws bagged together; everything reinstalls for standalone use
- ▶ Power from a standard grounded outlet; no special circuits needed at roughly 160 W average per unit

07 // IF SOMETHING'S NOT RIGHT

SYMPTOM	TRY THIS FIRST
App can't find the poster	Confirm your phone is on the poster's Wi-Fi (sticker on the back) or on the same venue network, then power-cycle the poster and reopen the app.
Content doesn't fill the screen	Check your file size against the canvas sizes in section 04, and confirm the group is set to the full wall, not a single unit.
Posters won't sync as a group	Confirm link cables are seated and every unit is powered, then re-publish to the group.
Remote update never arrives	The poster is probably offline. Confirm it is joined to venue Wi-Fi and shows online in VNNOX.
Anything else	Call or email us. Every SP poster carries a 2-year, US-based service warranty.

// OUTSIDE THE BOX DISTRIBUTION

52 O'Neil Street, Easthampton, MA
01027
US warehouse · MA showroom by
appointment

// SUPPORT

Aaron Diamond — Director
info@outsidetheboxdistribution.com
(631) 764-4601

// WARRANTY

2-year, US-based service warranty
Spare parts stocked in the US